

[Fanuc Controller](#)

[Fanuc Controller](#)>>[Mechanical](#)

[Fanuc Controller](#)>>[Mechanical](#)>>[ATC/APC](#)

Manual tool clamp

DESCRIPTION	The manual tool unclamp/clamp button on the control panel is working when the door is closed! If you accidentally press the tool change button it will make an tool unclamp and drop the tool on the table.
OVERHAUL OF PROCESS	Regarding the software update for door close avoid tool unclamp/clamp, please contact our service dept to provide the software update for recent machines.